asTech. Driven by Repairify

OPUS | IVS

One Collision Solution That Does it All



DriveSafe™

Choose Opus IVS for Your Repair Needs

TRUSTED
Most Top 5 MSOs rely on Opus IVS exclusively for superior scanning and calibration.

CERTIFIED
Opus IVS proudly holds OE certifications to meet program requirements with Expert Assisted True OE Scans.

ADVANCED
Designed and manufactured in-house in MIchigan, USA. Advanced technology used worldwide as essential tools in dealerships.

EXPERIENCE
Allow our brand-specific master techs to offer expert remote assistance.

FAST
With precise IVS Scans, giving you accurate results in as little as 1 minute.

Industry Leading Scanning
OE Scan - Certified, expert assisted OE scans with authentic OE reports

IVS Wizard - Easily guides you to the right scan every time

AIVS Scan - AI-powered repair insights on our trusted aftermarket scans, applicable to pre- and post-scans

Perform ADAS Calibrations In-House
ADAS MAP - Identification of ADAS Systems

IVS Calibrate - Calibrate static and dynamic yourself on-screen

Remote ADAS - Let us assist you in ADAS Calibrations

CCC Integration
Invoices and scan reports automatically integrate with CCC. Saving time and increasing accuracy

REPAIR REINVENTED (734) 222-5228 opt 1 OpusIVS.com

asTech
Driven by Repairify

OPUS | IVS

Enhanced Remote Expert Support with AiDN



AiDN Assist

The post-scan reveals multiple misfire codes (P0300, P0301, P0302, P0316), a turbo bypass valve issue (P0035), an O2 sensor circuit issue (P0153), and various other codes including tire pressure and vehicle speed abnormalities.

1. **Address Misfire Codes (P0300, P0301, P0302, P0316):**
   - Inspect and replace spark plugs and ignition coils for cylinders 1 and 2.
   - Check for vacuum leaks, fuel injector issues, and perform a compression test.
   - Verify the condition of the engine wiring harness and connectors.
2. **Turbo Bypass Valve Control Circuit High (P0035):**
   - Inspect the turbo bypass valve and its wiring for shorts or disconnections.
   - Test the bypass valve solenoid for proper operation and replace if necessary.
3. **O2 Sensor Circuit Slow Response (P0153):**
   - Inspect and possibly replace the O2 sensor on Bank 2, Sensor 1.
   - Check the wiring and connectors for any damage or corrosion.

With our revolutionary new AI advisor for your pre and post-scans - get estimates done faster with the AiVS pre-scan and get the car out the door faster with our AiVS postscan. With the AiVS PreScan, our AiDN Assess helps you understand the nature of the damage during the estimate phase of the repair, while our AiDN Assure content in the PostScan helps you fix what's wrong and get the car out of your shop.

Features

- **FAST & ACCURATE SCANS**
- **CCC INTEGRATION**
- **EXPERT ASSISTED OE SCAN**
- **REQUIRED ADAS CALIBRATIONS**

Benefits

- **PRECISE REPAIR PLANNING**
- **REDUCED CYCLE TIMES**
- **HIGHER PROFITS**

REPAIR REINVENTED

(734) 222-5228 opt 1

OpusIVS.com